



**SAFEKEY**  
A Simple Deterrent to **Impaired Driving.**

TechSheet: 167-02  
Rev.: 1.00  
Date: 3/3/2011  
Model: AM89  
Brand: SafeKey

---

## SafeKey AM89 Reprogramming Guidelines

### 1) Turn the Vehicle On

Turn the vehicles key to the on position.

### 2) Push the Valet Button

Push the button 3 times. It should then start blinking.

### 3) Push the Check Button

Locate the Check button on the remote and push and hold it for 3 seconds.

### 4) Shut the vehicle Off

Shut the Vehicle off and let the vehicle sit for 30 seconds.

